


CANON imageRUNNER ADVANCED Scan Basics

1. Touch **Scan and Send** from the Main Menu screen




2. Touch **Scan and Send** from the Main Menu screen Note: You can set advanced scan and send basic features by touching **Options**






CANON imageRUNNER ADVANCED Scan Basics

- 3. Chose what **Options** you will be using Note: Do not forget about page 2
- 4. Touch Close when finished



5. Touch Address Book


Note: If you want to send to a new destination not yet stored, touch **New Destination** \rightarrow enter the destination





CANON imageRUNNER ADVANCED Scan Basics

- 6. If you are sending to only one destination, touch a destination. If you are sending to multiple destinations, touch all the destinations
- 7. Touch OK
- 8. Touch Start



9. If the following screen appears, press **Start** button to scan the next original. After all of the originals are scanned, touch **Start Sending**

