



HP Add Fax Speed Dials from Web

- 1. In the address bar of the web browser of your choice, type in the **IP Address** of the copier
- 2. Click Fax on the top row
- 3. Click Fax Speed Dials on the left column




- 4. Check the box of the **Fax Speed Dial** you want to edit
- 5. Click **Edit** towards the bottom of the page





HP Add Fax Speed Dials from Web

- 6. Type in the Display Name
- 7. Type in the Fax Number
- 8. Click Add
- 9. Type in additional numbers as needed
- 10. Click OK



You should see **The operation was completed successfully** at the top of the screen when finished

