

Konica Print from User Box

- 1. Touch Menu button
- 2. Touch User Box

- 3. Touch desired User Box
- 4. Touch Open


- 5. Touch the File you want to print
- 6. Touch Print

- 7. Choose what print settings you need
- 8. Press Start









TO PLACE A SERVICE CALL OR ORDER SUPPLIES: CALL 800.847.3098 AND PROVIDE LOCATION AND SERIAL OR ID NUMBER OF THE DEVICE