

Konica Minolta Blank Page Removal - Scan

- 1. Place the originals in the Document Feeder
- 2. Select Scan/Fax main screen
- 3. Touch Application



4. Touch Original Settings



- 5. Touch Blank Page Removal
- 6. Touch **OK**
- 7. Touch Close
- 8. Touch Start

Open the file or Email attachment

Notice that the blank pages have been removed

