


Konica Minolta Card Shot

- 1. Lift the **Cover** and place card in the upper left corner of the platen glass SEF (Short Edge First)
- 2. Touch Application tab



- 3. Scroll (right) or press J Icon to locate Card Shot
- 4. Touch Card Shot



- 5. Turn ON Card Shot Function
- 6. Enter the X and Y values now using (& +)
- 7. Touch any Size button to lock in your value
- 8. Touch **OK**
- 9. Press **Start** to scan the front side
- 10. When prompted, flip card over to back side and place card back in the upper left corner of the platen glass
- 11. Press Start
- 12. When prompted, touch Finish and press Start

